

Toner Quick Reference Guide

MFC / FAX

TN-1050	DR-1050	●	MFC-1810	MFC-1910W		
TN-2110 TN-2120	DR-2100	●	MFC-7320	MFC-7440N	MFC-7840W	
TN-2210 TN-2220	DR-2200	●	MFC-7360N MFC-7460DN	MFC-7860DW	FAX-2840	FAX-2845 FAX-2940
TN-3130 TN-3170	DR-3100	●	MFC-8460N	MFC-8860DN	MFC-8870DW	
TN-2310 TN-2320	DR-2300	●	MFC-L2700DW	MFC-L2700DN	MFC-L2720DW	MFC-L2740DW
TN-3230 TN-3280	DR-3200	●	MFC-8370DN	MFC-8380DN	MFC-8880DN	MFC-8890DW
TN-3330 TN-3380	DR-3300 TN-3390†	●	MFC-8510DN	MFC-8520DN	MFC-8950DW†	MFC-8950DWT†
TN-3430 TN-3480 TN-3512*	TN-3520** DR-3400	●	MFC-L5700DN MFC-L6900DW*/**	MFC-L5750DW MFC-L6900DWT*/**	MFC-L6800DW*	MFC-L6800DWT*
TN-130 TN-135	DR-130CL	●●●●	MFC-9440CN	MFC-9450CDN	MFC-9840CDW	
TN-230	DR-230CL	●●●●	MFC-9120CN	MFC-9320CW		
TN-241 TN-245	DR-241CL	●●●●	MFC-9140CDN	MFC-9330CDW	MFC-9340CDW	
TN-320 TN-325	TN-328† DR-320CL	●●●●	MFC-9460CDN	MFC-9465CDN	MFC-9970CDW†	
TN-321 TN-326	TN-329*** DR-321CL	●●●●	MFC-L8650CDW	MFC-L8850CDW***		
TN-421 TN-423	TN-426† DR-421CL	●●●●	MFC-L8690CDW	MFC-L8900CDW†		
TN-900	DR-321CL	●●●●	MFC-L9550CDWT			
TN-910	DR-421CL	●●●●	MFC-L9570CDW	MFC-L9570CDWT		

HL / DCP

TN-1050	DR-1050	●	HL-1110 HL-1112/A	HL-1210W HL-1212W	DCP-1510 DCP-1512/A	DCP-1610W DCP-1612W
TN-2005	DR-2005	●	HL-2035	HL-2037		
TN-2010	DR-2200	●	HL-2130 HL-2132	HL-2135W	DCP-7055 DCP-7055W	DCP-7057
TN-2110 TN-2120	DR-2100	●	HL-2140 HL-2150N	HL-2170W	DCP-7030 DCP-7032	DCP-7040 DCP-7045N
TN-2210 TN-2220	DR-2200	●	HL-2240 HL-2240D	HL-2250DN HL-2270DW	DCP-7060D DCP-7065DN	DCP-7070DW
TN-2310 TN-2320	DR-2300	●	HL-L2300D HL-L2340DW	HL-L2360DN HL-L2365DW	DCP-L2500D DCP-L2520DW	DCP-L2540DN DCP-L2560DW
TN-3130 TN-3170	DR-3100	●	HL-5240 HL-5240L	HL-5250DN HL-5270DN	HL-5280DW DCP-8060DN	DCP-8065DN
TN-3230 TN-3280	DR-3200	●	HL-5340D HL-5340DL	HL-5350DN HL-5350DNLT	HL-5370DW HL-5370DWT	HL-5380DN DCP-8070D DCP-8085DN
TN-3330 TN-3380	TN-3390† DR-3300	●	HL-5440D HL-5450DN	HL-5450DNT HL-5470DW	HL-6180DW† HL-6180DWT†	DCP-8110DN DCP-8250DN†
TN-3430 TN-3480 TN-3512*	TN-3520** DR-3400	●	HL-L5000D HL-L5100DN HL-L5100DNT	HL-L5200DW HL-L5200DWT HL-L6250DN*	HL-L6300DW* HL-L6300DWT* HL-L6400DW*/**	HL-L6400DWT*/** DCP-L5500DN DCP-L6600DW*

HL / DCP

	TN-130 TN-135	DR-130CL		HL-4040CN HL-4050CDN	HL-4070CDW	DCP-9040CN DCP-9042CDN	DCP-9045CDN
	TN-230	DR-230CL		HL-3040CN HL-3070CW	DCP-9010CN		
	TN-241 TN-245	DR-241CL		HL-3140CW HL-3150CDW	HL-3170CDW	DCP-9015CDW DCP-9020CDW	
	TN-320 TN-325	TN-328 [†] DR-320CL		HL-4140CN HL-4150CDN	HL-4570CDW[‡] HL-4570CDWT[‡]	DCP-9055CDN DCP-9270CDN[‡]	
	TN-321 TN-326	TN-329*** DR-321CL		HL-L8250CDN	HL-L8350CDW***	DCP-L8400CDN	DCP-L8450CDW***
	TN-421 TN-423	TN-426** DR-421CL		HL-L8260CDW	HL-L8360CDW**	DCP-L8410CDW	
	TN-900	DR-321CL		HL-L9200CDWT	HL-L9300CDWT		
	TN-910	DR-421CL		HL-L9310CDW	HL-L9310CDWT	HL-L9310CDWTT	

Genuine Brother Supplies

Why choose Genuine Brother Supplies?

Genuine Brother ink and toners are the result of extensive research and development of over 100 different elements. Our toners are engineered to ensure each print is right first time, every time - with reliable operation, protection of the machine and long life print head guaranteed. Using non Brother supplies may affect hardware performance, copy quality and machine reliability.



Toner Cartridges

Genuine Brother toner cartridges are designed specifically to work with our laser system design. Each component of a Brother laser product is designed to work with the other.

All original Brother toner cartridges are manufactured to the highest possible standards in controlled clean rooms. Each cartridge is rigorously tested in order to assure users of the quality and performance they expect.

Working with you for a Better Environment

As part of our ongoing commitment to the environment Brother has teamed up with the Cool Earth charity to protect part of the Amazon Rainforest in Peru. In doing this we are preventing deforestation, reducing CO² emissions and allowing plant and animal life to thrive.

For more details go to: www.coolearth.org/brother



For further information visit: www.brother.eu/supplies